

EHD-510

EHD-420

EHD-410

BASYS® Style Rush Street® Style Clark Street® Style

**HAND DRYER SPOUT PARTS LIST**

Item No.	Code No.	Part No.	Description
1	0366050	EHD-511-A	BASYS Style Dryer Spout Repair Kit (Chrome)*
2	0366016	EHD-516-A	BASYS Style Dryer Crown Kit (Chrome)*
3	33660023	EHD-421	Rush Street Style Dryer Spout Repair Kit (Chrome)*
4	33660037	EHD-422	Rush Street Sensor Repair Kit
5	33660028	EHD-411	Clark Street Style Dryer Spout Repair Kit (Chrome)*
6	33660038	EHD-412	Clark Street Sensor Repair Kit
7	0366015	EHD-515-A	BASYS Holding Nut Assembly Repair Kit - Single Thread
	33660036	EHD-415	Rush and Clark Street Holding Nut Assembly Repair Kit - Double Thread
8	0366008	EHD-512-A	Hose and Muffler Repair Kit
9	0366009	EHD-513-A	Motor Assembly 110/120V with HEPA Filter (Plug type B)
	03660029	EHD-517-A	Motor Assembly 220V with HEPA Filter (International Only, Plug type M)
10	0366014	EHD-514-A	HEPA Filter Repair Kit (Filter with screen)

\* Consult factory for alternate finish options. Replacement Dryer Spouts include respective Holding Nut (Item No. 3).

