

## DROPSHOT™ CARE AND CLEANING GUIDE



DRS-120 in Stainless Steel



DRS-120 in Black Powder Coat

### !!! IMPORTANT !!!

**DO NOT MIX CLEANING SOLUTIONS.  
ALWAYS READ CLEANING PRODUCT  
LABELS FOR PROPER USE.**

**Note:** The information in this document applies to all DropSpot™ models.

### STAINLESS STEEL SURFACES

#### General, everyday cleaning

Use only a mixture of clean water and a mild detergent to clean unit daily or as often as needed. For best results, always rinse well with fresh water and wipe completely dry with a clean, soft, microfiber cloth.

DO NOT apply cleaner directly to the unit surfaces; apply the cleaner to the microfiber cloth to clean.

#### To remove stubborn water marks or minor scratches

Apply a stainless steel cleaner/polish to a synthetic abrasive pad and carefully rub the panel with the grain. ALWAYS RUB IN THE DIRECTION OF THE GRAIN.

#### To disinfect

Use a solution of clean water and rubbing alcohol. Spray solution onto a soft cloth and wipe down the stainless steel surfaces only. Wipe completely dry with a separate clean, dry cloth. Be sure to always wipe or rub in the direction of the grain to maintain the finish.

#### DO NOT USE

- Harsh, ammonia or acid based chemicals
- Abrasive, petroleum based cleaners
- Abrasive sponges or brushes
- ZEP Spirit II
- 3M™ Quat disinfectant

### BLACK POWDER COATED SURFACES

#### General, everyday cleaning

Use only a mixture of clean water and a mild detergent to clean unit daily or as often as needed. For best results, always rinse well with fresh water and wipe completely dry with a clean, soft, microfiber cloth.

DO NOT apply cleaner directly to the unit surfaces; apply the cleaner to the microfiber cloth to clean.

#### DO NOT USE

- Harsh, ammonia or acid based chemicals
- Abrasive, petroleum based cleaners
- Abrasive sponges or brushes
- ZEP Spirit II
- 3M™ Quat disinfectant
- Sodium hydroxide
- Methanol, ethanol, and Isopropyl (rubbing alcohol) solutions

### PLASTIC AND RUBBER COMPONENTS

#### General, everyday cleaning

The bubbler, push bar, and bottle filler alcove are made of antimicrobial material, prohibiting the growth of microorganisms. Use only a mixture of clean water and a mild detergent to clean unit daily or as often as needed. For best results, always rinse well with fresh water and wipe completely dry with a clean, soft, microfiber cloth.

DO NOT apply cleaner directly to the unit surfaces; apply the cleaner to the microfiber cloth to clean.

The brands and/or products names referenced herein may be subject to trademark rights of their respective owners.

Use of the brands and names is for identification purposes only and does not imply affiliation with or endorsement by Sloan.

The information contained in this document is subject to change without notice.

**When assistance is required, please contact Sloan  
Technical Support at 1.888.SLOAN.14 or 1.888.756.2614.**

**SLOAN • 10500 SEYMOUR AVENUE • FRANKLIN PARK, IL 60131**

Phone: +1.800.9.VALVE.9 or +1.800.982.5839 • Fax: +1.800.447.8329 • www.sloan.com